

EPIC ENTERPRISES, INC.

Flat & Premolded Brake Linings & Brake Lining Installation Tool for Volkmann 06-09 BA1-BA3



*Parts and Services
you can rely on!*

EPIC ENTERPRISES, INC.

P O Box 979
Southern Pines NC 28388-0979
845 Valley View Road
Southern Pines NC 28387

Phone: 910-692-5441 or Toll Free: 800-648-7273
Fax: 910-692-4147 or Toll Free: 888-692-4147
Email: epic@epicenterprises.com

Installation Instructions using EE480174 Brake Lining Tool:

1. Remove old brake lining
2. Clean spindle whorl (inside)
3. Place new brake lining in larger opening of brake lining cylinder. Match the two ends together and evenly apply pressure to the lining with fingers. Push inside opening of cylinder.
4. Using plunger part of tool, push the lining to the bottom internal lip of cylinder.
5. Place cylinder with brake lining on bottom of spindle whorl.
6. Using plunger with anvil, hammer the anvil part until brake lining slides into cavity at base of spindle whorl.
7. Remove brake lining tool; use plunger to seat lining in cavity of spindle whorl.

Note: When using EE480174 Tool on BA1 & BA2 Spindles, place adaptor ring in cylinder and secure with the three screws provided. For BA3 Spindles, the adaptor ring is not used.



Epic Enterprises, Inc.
Parts & Services
You Can Rely On!

Prices are subject to change

Volkmann is a trademark of Saurer AG

EE is an Epic trademark designating Epic parts

© Epic Enterprises, Inc. February 2003